



# Sequential Mating Box

## Checking Microswitch Connections

Plug the lead into the connector on the rear of the sequential box.

When the L3 Lock on the box is UNLOCKED

There should be a circuit between the Black and Brown wires on the lead.  
(BUZZ)

There should be NO circuit between Black and Blue wires on the lead.  
(NO BUZZ)

When the L3 Lock on the box is LOCKED

There should be NO circuit between the Black and Brown wires on the lead.  
(NO BUZZ)

There should be a circuit between the Black and Blue wires on the lead.  
(BUZZ)

**LED connects to the Brown and Blue Terminals on final assembly**

